#### JUMO GmbH & Co. KG

Delivery address: Mackenrodtstraße 14,

36039 Fulda, Germany
Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
e-mail: mail@jumo.net
Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House

Temple Bank, Riverway
Harlow, Essex CM 20 2TT, UK
Phone: +44 1279 635533
Fax: +44 1279 635262
e-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13031, USA Phone: 315-697-JUMO 1-800-554-JUMO

Fax: 315-697-5867 e-mail: info@jumo.us Internet: www.jumo.us



Data Sheet 70.3046

Page 1/10

## JUMO dTRON 304 plast/ 308 plast Compact Controller for the plastics industry

### **Brief description**

The JUMO dTRON 300 plast series of controllers consists of two freely programmable instruments in different DIN formats for controlling temperature and other process variables, to suit the special applications of the plastics industry. Such applications include extruders, injection-molding machinery, tempering equipment and hot-channel systems.

The high-contrast, multicolor LC display for process value, setpoint and operator prompting contains two four-digit 7-segment displays, two single-character 16-segment displays, display of the active setpoints, six status indicators, and displays for the unit, ramp function and manual operation.

Simple operation through 4 keys. The instruments can be used as 2-state, 3-state, modulating or continuous controllers. The controller software includes a hot-channel warm-up ramp function, control loop and output level monitoring, two autotuning (self-optimization) procedures, a math and logic module, as well as 4 limit comparators.

Linearizations for the usual transducers are stored, and a customer-specific linearization table can be programmed.

A setup program is available for user-friendly configuration from a PC.

An RS422/485, a PROFIBUS-DP or current interface can be used to integrate the instruments into a data network.

The electrical connection is made at the back, via screw terminals.

The possible input and output configurations are shown in the following block diagram. The option boards are universally applicable for all instruments in the series.




JUMO dTRON 308 plast Type 703046/ ...



JUMO dTRON 304 plast Type 703048/ ...

#### **Block structure**



### Option boards:

- 2 binary inputs
- 1 relay 230 V/8 A, changeover (SPDT)
- 2 relays 230V/3A, make (SPST-NO), with common pole
- 1 solid-state relay
- analog output (voltage/current)
- RS422/485 interface
- PROFIBUS-DP interface
- current interface 0/20mA

## **Key features**

- Control loop monitoring
- Output level monitoring
- Hot-channel warm-up ramp
- Heater current monitoring
- MODbus master function
- Boost function
- Four programmable setpoints, two parameter sets
- Math and logic module
- Two autotuning procedures
- Fast, user-friendly configuration through the setup program with program editor
- RS422/485 interface
- PROFIBUS-DP interface
- Current interface 0/20mA (as per Euromap)
- cUL/UL approval applied for

## **Autotuning**

Standard features include the tried and tested autotuning facility, which makes it possible for the controller to be matched to the control loop by a user who is not a control-technology expert.

This functions by evaluating the response of the control loop to specific changes in the output level. Either an oscillatory method or a step-response test can be selected. The step-response test is used, for example, in the plastics industry or in processes where the oscillatory method cannot be employed. The controller parameters that are calculated are: proportional band, reset time, derivative time, cycle time and filter time constant.

# Customer-specific linearization

In addition to the linearizations for the usual transmitter outputs, a customer-specific linearization can be created. The programming is carried out in the setup program, in the form of a table of values or a formula.

#### **User data**

Parameters which frequently have to be changed by the user can be combined at the user level, under "User data" (only through the setup program).

## Math and logic module<sup>1</sup>

The math module makes it possible to combine values such as setpoints, output levels and measurements from the analog inputs into a mathematical formula.

The logic module can, for instance, be used to logically combine binary inputs and limit comparators with one another.

Up to two math or logic formulae can be entered through the setup program, and the results of the calculations can be presented at the outputs or used for internal purposes.

## Special types of controller<sup>1</sup>

The instrument can be operated as a difference, humidity or ratio controller.

## **Binary functions**

- Start boost function
- Start/cancel autotuning
- Change to manual mode
- Hold/cancel ramp
- Controller off
- Setpoint switching
- Parameter set switching
- Key/level inhibit
- Text display
- Display off
- Acknowledge limit comparators
- Program start/hold/cancel
- Timer start/stop

Several binary functions can be combined with one another (only through the setup program).


1. Extra code

## **Functions of the outputs**

- Analog input variables
- Math
- Process value
- Setpoint
- Ramp end value
- Control deviation
- Output level
- Controller outputs
- Limit comparators
- Control contacts
- Binary inputs
- Logic formula
- Program end
- Timer signals
- Program/automatic signal

## **Ramp function**

Either a rising or a falling ramp function can be used (increase or decrease in the setpoint). The setpoint value SP changed at time  $t_0$  is the final value for the ramp. The ramp starts with the setpoint at time  $t_0$ . The slope of the ramp can be programmed; the sign of the slope is given by the relationship between the setpoint at time  $t_0$  and the SP value. When the supply voltage is switched on, the ramp function starts with the momentary process value.



### **Timer**

A timer is available for time-dependent control. The status of the timer can be switched through to the binary outputs or internally processed for the activation or deactivation of time-dependent processes.

## Setup program (accessory)

The setup program for configuring the instrument is available in English, French, German, and other languages. Using a PC, you can create and edit sets of data, and transfer them to the controller or read them out from the instrument. The data sets are stored and managed.


The setup program can be expanded through additional program modules.

#### **Program editor**

For the easy creation of programs.

#### Start-up

To check the control behavior.



## **Displays and controls**



- (1) **7-segment display** (factory setting: process value) four-digit, red; decimal place is configurable (automatic adjustment on display overflow)
- (2) Active setpoint (factory setting: SP1) SP1, SP2, SP3, SP4 (SP=setpoint); green;
- (3) 7-segment display (factory setting: setpoint) four-digit, green; decimal place is configurable; also used for operator prompting (display of parameter and level symbols)
- (4) Keys
- (5) Indication

yellow, for

- switch status of binary outputs 1 6 (display lights up = on)
- ramp/program function is active
- manual operation is active
- (6) 16-segment display for the unit °C/°F and text

two-digit, green; symbols for h, min and % additional display options through the setup program

### **Program function**


A setpoint profile can be implemented with a maximum of 8 program segments. The settings for the segment setpoints and segment times are carried out at the user level. The time scale can be configured as mm:ss or hh:mm (s = seconds, h = hours).

A program-end signal can be generated, and the program can be halted or canceled.

Further functions can be defined through the setup program (start at process value, cyclical program handling, segment-by-segment assignment of parameter sets and four control contacts). The program profile can also be visualized.

### Warm-up ramp for hot channel

The warm-up ramp for hot-channel equipment is used, for example, for the gentle operation of ceramic heater elements. Damage can be avoided by allowing moisture to evaporate slowly from the hydroscopic heater elements during the warm-up phase.



#### **Boost function**

Time- or event-controlled setpoint boost, for example for tool nozzle retraction during the production process. The temperature of the zones is raised by an adjustable value for an adjustable time period, via the binary function (factory setting: binary input 1 (pushbutton)).

## **Reduction function**

The temperature of the zones can be lowered to a quiescent-state setpoint during the production process, for cleaning or changing tools. Ex-factory, this is carried out via binary input 2, but can also be activated through a different signal.

#### **Control loop monitoring**

Control loop monitoring is used to check whether the process reacts as expected during commissioning and the approach phase. What is checked is how the process value changes with respect to changes in the output level.

In addition, control loop monitoring also detects any polarity reversal of the operating sense (heating ON, process value falls).

If the (adjustable) conditions are not fulfilled, an alarm will be triggered.

### **Output level monitoring**

This functions serves to monitor the control loop during operation. Output level monitoring is available for checking whether the output level (in a stabilized condition) moves within definable limits (monitoring band) about an average output level. The average output level is calculated by the instrument by means of an adjustable determination time ty. If the output level goes outside the monitoring band, an alarm signal is initialized. This serves to indicate a heating failure or changes to the sensor, for instance.

### **Interfaces**

#### RS422/RS485 interface

The serial interface is used for communication with higher-level (supervisory) systems.

The MODbus protocol is used for transmission.

#### **PROFIBUS-DP**

The PROFIBUS-DP interface can be used to integrate the controller into a fieldbus system operating according to the PROFIBUS-DP standard. This PROFIBUS variant is especially designed for communication between automation systems and decentralized peripheral devices at the field level, and optimized for speed.

Data transmission is made serially, using the RS485 standard.


GSD generator, the project-planning tool that is supplied with the package (GSD = Gerätestammdaten, i.e. device data), is used to make a selection of device characteristics for the controller, to create a standardized GSD file that is used to integrate the controller into the fieldbus system.

#### **Current interface**

Serial interface with 0/20 mA as per Euromap. Communication takes place through the MODbus or Arburg protocol.

### **MODbus** master

The instrument can be used as an independent master within a MODbus network. This enables the transmission of data to all the devices (slaves (max. 32)) in the MODbus network, either by a key stroke or through the binary function. The slaves must all be devices of the same type. The configuration is performed through the Setup program.



### **Parameter level**

All parameters and their meanings are listed in the table below. Some parameters may be missing or meaningless for a particular type of controller. Two parameters sets can be stored, to handle special applications.

Parameter	Value range	Factory setting	Meaning
Proportional band	0 to 9999 digits	0 digits	Size of the proportional band 0 means that the controller structure is out of action!
Derivative time	0 to 9999 sec	80 sec	Influences the differential component of the controller output signal
Reset time	0 to 9999 sec	350 sec	Influences the integral component of the controller output signal
Cycle time	0 to 999.9 sec	20.0 sec	When using a switched output, the cycle time should be chosen so that the energy flow to the process is as continuous as is practicable without overloading the switching elements.
Contact spacing	0 to 999.9 sec	0.0 digits	The spacing between the two control contacts for 3-state or modulating controllers
Switching differential	0 to 999.9 digits	1.0 digits	Hysteresis for switching controllers with proportional band = 0
Actuator time	5 to 3000 sec	60 sec	Actuator time range used by the control valve for modulating controllers
Working point	-100 to +100%	0%	The output level for P and PD controllers (if $x = w$ then $y = Y0$ ).
Output level limiting	0 to 100%	100%	Maximum output level
	-100 to +100 %	-100%	Minimum output level

## **Technical data**

## Input for thermocouple

Designation		Measuring range	Measuring accuracy	Ambient temperature error
Fe-Con L		-200 to + 900°C	≤0.25%	100 ppm /°C
Fe-Con J	EN 60 584	-200 to +1200°C	≤0.25%	100 ppm /°C
Cu-Con U		-200 to + 600°C	≤0.25%	100 ppm /°C
Cu-Con T	EN 60 584	-200 to + 400°C	≤0.25%	100 ppm /°C
NiCr-Ni K	EN 60 584	-200 to +1372°C	≤0.25%	100 ppm /°C
NiCr-Con E	EN 60 584	-200 to +1000°C	≤0.25%	100 ppm /°C
NiCrSi-NiSi N	EN 60 584	-100 to +1300°C	≤0.25%	100 ppm /°C
Pt10Rh-Pt S	EN 60 584	0 to 1768°C	≤0.25%	100 ppm /°C
Pt13Rh-Pt R	EN 60 584	0 to 1768°C	≤0.25%	100 ppm /°C
Pt30Rh-Pt6Rh B	EN 60 584	0 to 1820°C	≤0.25% <sup>1</sup>	100 ppm /°C
W5Re-W26Re C		0 to 2320 °C	≤0.25%	100 ppm /°C
W3Re-W25Re D		0 to 2495 °C	≤0.25%	100 ppm /°C
W3Re-W26Re		0 to 2400 °C	≤0.25%	100 ppm /°C
Cold junction			Pt100, internal	

<sup>1.</sup> within the range 300 to 1820  $^{\circ}\text{C}$ 

### Input for resistance thermometer

Designation		Connection circuit	Measuring range	Measuring	gaccuracy	Ambient temperature error
				3-/4-wire	2-wire	
Pt100	EN 60 751	2-wire / 3-wire / 4-wire	-200 to +850°C	≤0.05%	≤0.4%	50 ppm / °C
Pt500	EN 60 751	2-wire / 3-wire / 4-wire	-200 to +850°C	≤0.2%	≤0.4%	100 ppm /°C
Pt1000	EN 60 751	2-wire / 3-wire / 4-wire	-200 to +850°C	≤0.1%	≤0.2%	50 ppm /°C
KTY11-6		2-wire	-50 to +150°C	≤1.0%	≤2.0%	50 ppm /°C
Sensor lead re	esistance		$30\Omega$ max. per lead fo	r 3-wire/4-wii	re circuit	
Measuring current		approx. 250μA				
		•	Not required for 3-wire or 4-wire circuit. With a 2-wire circuit, the lead resistance can be compensated in software by a correction of the process value.			

## Input for standard signals

Designation	Measuring range	Measuring accuracy	Ambient temperature error
Voltage	0(2) - 10V 0 - 1V input resistance R <sub>IN</sub> > 100kΩ	≤0.05% ≤0.05%	100 ppm / °C 100 ppm / °C
Current	0(4) — 20mA, voltage drop ≤ 1.5V ≤0.05% 100 ppm /		100 ppm / °C
Heating current	0 — 50mA AC	≤1%	100 ppm / °C
Resistance transmitter	min. 100 $\Omega$ , max. 4k $\Omega$	≤0.5%	100 ppm / °C

## **Binary inputs**

Floating contacts	

## Standard version

## Measuring circuit monitoring

In the event of a fault, the outputs move to a defined (configurable) status.

Sensor	Overrange / underrange	Probe or lead short-circuit	Probe or lead break
Thermocouple	•	-	•
Resistance thermometer	•	•	•
Voltage 2 — 10V 0 — 10V	•	-	-
Current 4 — 20mA 0 — 20mA	•	-	• -

<sup>• =</sup> recognized -= not recognized

## Outputs

Relay, changeover (SPDT) contact rating contact life	3A at 230V AC resistive load 350,000 operations at rated load / 750,000 operations at 1A
Relay, changeover (SPDT), option	550,000 operations at rated load / 750,000 operations at TA
contact rating	8A at 230VAC resistive load
contact life	100,000 operations at rated load / 350,000 operations at 3A
Relay, make (SPST-NO)	
contact rating	3A at 230VAC resistive load
contact life	350,000 operations at rated load / 900,000 operations at 1A
Logic output	0/12V / 24mA max. (sum of all output currents) or
	0/18V / 24mA max. (sum of all output currents)
Solid-state relay (option)	
contact rating	1A at 230V
protection circuitry	varistor
Voltage (option)	
output signals	0 - 10V/2 - 10V
load resistance	$R_{load} \ge 500\Omega$
Current (option)	
output signals	0 — 20mA / 4 — 20mA
load resistance	R <sub>load</sub> ≤500Ω
Supply voltage for	
2-wire transmitter	electrically isolated, not stabilized
voltage	30V with no load
	23V at 30mA

## Controller

Controller type	2-state controller,	
	3-state controller, modulating controller, continuous controller	
Controller action	P/PD/PI/PID	
A/D converter	dynamic resolution up to 16-bit	
Sampling cycle time	250msec	
	50msec, 90msec, 150msec, 250msec	

## Electrical data

Supply voltage (switch-mode PSU)	110 — 240V AC -15/+10%, 48 — 63Hz
	20 – 30 V AC/DC, 48 – 63 Hz
Electrical safety	to EN 61 010, Part 1
	overvoltage category II, pollution degree 2
Power consumption	13VA max.
Data backup	EEPROM
Electrical connection	at the back, via screw terminals,
	conductor cross-section up to 2.5 mm <sup>2</sup>
	with core ferrules (length: 10mm)
Electromagnetic compatibility	EN 61 326
interference emission	Class B
interference immunity	to industrial requirements

## Stock version

## Housing

•	
Housing type	plastic housing for panel mounting to DIN 43 700
Depth behind panel	90 mm
Ambient/storage temperature range	0 to 55°C / -40 to +70°C
Climatic conditions	rel. humidity ≤ 90% annual mean, no condensation
Operating position	horizontal
Enclosure protection	to EN 60 529, front IP65 / back IP20
Weight (fully fitted)	Type 703046: approx. 380g
	Type 703048: approx. 490 g

## Interface

### **MODbus**


Interface type	RS422/485
Protocol	MODbus, MODbus-integer
Baud rate	9600, 19200, 38400
Device address	0 — 255
Max. number of stations	32

### Profibus-DP


### **Current interface**

Interface type	current 0/20mA
Protocol	MODbus, MODbus-integer, MODbus master
Baud rate	4800, 9600, 19200, 38400
Device address	0 — 255
Max. number of stations	32


## Connection diagram, type 703046/48




## **Terminal strip 3**



### **Terminal strip 2**





### **Terminal strip 1**




## **Dimensions**













## Type 703048









Side-by-side Minimum spacing	•	outs
Туре	horizontal	vertical
without setup plug:		
703046	11 mm 11 mm	30mm
703048	11mm	30mm
with setup plug (see arrow	):	
703046	11mm	65mm
703048	11mm	65mm

## **Order details**

3046																	
	JUMO incl. 2	O dT	RO	N308,	, 48 2 hi	mm	x 9	6mı	n fo	rma	t (po	ortrai	t fo	rmat)			
3048	JUMO	Tb C	RO	and 2 binary inputs, 2 relays and 2 logic outputs  \$\text{304, 96mm x 96mm format}  and 2 binary inputs, 2 relays and 2 logic outputs													
	incl. 2	2 an	alog	and 2	2 bi	nar	/ inp	uts,	2 r	elays	an	d 2 I	ogi	c outputs			
			1	Poo	Basic type extensions												
	2			Bas				ens	IOTI	5							
	_			Vers			_										
		8		Star													
		9		Prog													
	_		4				outs	(2 a	re a	avail	able	e as	sta	ndard)			
			1 2		0 / 12V 0 / 18V												
	4	1	1	0,	10 0												
				1	1. 5	2. ;	3. (	nti	on s	slot					Maximum number of options		
				<u> </u>	_			-	ısec								
												ınive			1		
												er (S			2		
										mal outpu		SPST	-N(	O)	2		
										inpu					2		
					_					ate re		1A			2		
					-	7						face			1		
												nterf			1		
				L	-	9	9 (	Curr	ent i	nter	face	0/2	0 m	A	1		
	-= not allowed in this option slot									lowe	d in	this	opti	ion slot			
										-							
								0		_	ıpp	-	21.7	AO 45/.400/	40 0011-		
										11	0 –	- 240		AC -15/+10%,			
										11	0 –	- 240		AC -15/+10%, C/DC, 48 — 63			
										11	0 –	- 240					
										11	0 –	- 240		C/DC, 48 — 63			
										11	0 -	- 24( 30V	AC	C/DC, 48 - 63			
										11	0 -	- 240 30V	AC	Extra codes none	Hz		
										11	0 -	- 240 30V 0	AC	Extra codes none Math and logi	tz c module		
										11	0 -	0 1	0 4	Extra codes none	c module		
										11	0 - 0 - 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle	tz module er troller		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference col	to module  er troller		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference col	c module er etroller		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference controlle Humidity controlle	c module er troller Approvals		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference con Humidity conf	c module or itroller roller  Approvals none		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference controlle Humidity controlle	c module er troller Approvals		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference con Humidity conf	c module or itroller roller  Approvals none		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference con Humidity conf	c module or itroller roller  Approvals none		
										11	0 - 0 - 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference con Humidity conf	c module or itroller roller  Approvals none		
	/ 2				1			2		11	0 - 0 - 2 2 2 2 2	0 1 1	0 4 7 8	Extra codes none Math and logi Ratio controlle Difference con Humidity conf	c module or itroller roller  Approvals none		

= stock versions

Scope of delivery: - controller

- sea
- mounting brackets
- Operating Manual B70.3046.0 in DIN A6 format

1 mini-CD with the demo setup software and pdf documents in DIN A4 format (operating manual and additional documentation) can be ordered separately. The individual documents and programs are downloadable from www.jumo.net (the software can be enabled for a charge).